


**6** Place the net over the frame. The NWS label indicates the top of the net ensure this is at the top of the crossbar. Align the side seams with the back bars so that the net sits comfortably over the goal.

**7** Starting with the top corners, fit the net by wrapping it around the posts and clipping to the inside using the bungee ties provided. Attach Bungees equally along the length of the net.



**8** Anchor the goal using the provided U-pegs ensuring posts are upright and the crossbar is level. The U-pegs fit around the base and push into the ground to keep the goal steady.



## WATCH THE VIDEOS

*Learn how to assemble your goal and take your game to the next level.*

[www.youtube.com/networldsports](http://www.youtube.com/networldsports)



Always Inspect goal post and net for defects before use and repair damaged parts in accordance with BS 8461:2005 code of practice.

Do not use goal with faulty parts.

The goal must always be secured to the ground. Weights to be used on hard surfaces, ground anchors on grass.

Never climb on the net or goal frame. The goal must never be used without the net fitted.

Please adhere to safety instructions at all times.

CAUTION: it is recommended that a minimum of 2 people assemble this product.

### Additional Information

When the goal is not being used dismantle and store under cover.

This goal conforms with BS8462:2005.

Not suitable for children under 3 years.

It is recommended that the goal is assembled by an adult.

Warranty excludes net.


Please see [forzaggoal.com/forza-goal-instructions](http://forzaggoal.com/forza-goal-instructions) for more details.



@NetWorldSports

# FORZA

## 12 x 6 STEEL42



PART NO	1a	1b	2	3	4	5a	5b	6	7	8	10	11a	11b	12	U-PEGS	BUNGEE TIES	NET
QTY	x1	x1	x4	x2	x4	x1	x1	x4	x2	x1	x2	x1	x1	x2	x1 PCK	x1 PCK	x1


**NET WORLD SPORTS»**

[www.networldsports.co.uk](http://www.networldsports.co.uk) // +44 (0) 1691 683 807 // [cs@networld-sports.co.uk](mailto:cs@networld-sports.co.uk)


[www.networldsports.com](http://www.networldsports.com) // 1-866-861-9095 // [cs@networld-sports.com](mailto:cs@networld-sports.com)

**1** Lay out all components and ensure that they match the parts list.


**2** Assemble the base, using parts 3, 4, 6, 12, 5a & 5b.



**3** Insert the uprights (part 2) and the back bars (parts 4 & 10) into the base.



**4** Assemble the top of the goal frame using parts 1a, 1b, 2, 6, 8, 11a & 11b.



**5** Attach the top of the goal frame to the uprights and backbars.  
NOTE: it is advised that two people lift and join the top of the goal to the frame.

